

## **Storm Panels (Aluminum)**

## **Measuring Instructions:**

## For Panels:

- Measure the opening width and height
- If measuring a door be sure to measure height from the floor to top of opening (for mounting sill to floor).
- If door has steps, measure the height from the top of the step to the top of the opening (for mounting sill to top of front of steps).
- Download Panel Chart to determine finished width of opening & number of panels needed.
- Add 6" to height for window & 3" for Door
- Standard H-Header top track & studded angle bottom track are included.

Example:

Finish Size 36x63 63"
Shutt

36"

Shutter Finished Size 39"W x 69"H