



Installation Instructions for Bahama Shutters

Tools required: Hammer Drill, 5/16 Drill Bits, 5/16 Driver, Hammer and # 3 screw driver.

1. Start holes 1" minimum to 3" maximum from the end of hinge.
2. Drill Bahama hinge out every 12" for concrete and 6" for wood.
3. Mount hinge onto house with 2 1/2" minimum screws. Use Tapcon for cement buildings and Woodscrew
4. Slide Bahama into hinge. NOTE: if you do not have room, slide Bahama on hinge and then mount.
5. Install Bahama arm to Bahama with bolts.
6. Keep Bahama in closed position and Bahama arm closed. Mount camel back to wall in closed position.
7. Mount angle locks onto side of Bahamas.