



## **Installation Instructions for Clear Shutters**

1. Locate center of window and mark.
2. Locate center of H-Header and mark.
3. Pre-drill starter holes in H-Header
4. Pre-drill holes in F-Track
5. Your H-Header comes pre-cut to fit your window
6. Drill the first hole for the H-Header
7. Drill in the first Tapcon screw
8. Level the H-Header and drill the remaining holes.
9. Line up the F-Track
10. Drill first hole in the F-Track.
11. Drill the first Tapcon in the F-Track
12. Level the F-Track and drill the remaining holes.
13. Slide the mounting screws into the F-Track
14. Put the panel in place
15. Wing nut the panels in place
16. The panels will overlap each other across the window